

ELD

Quick Start Guide



WE'RE CONFIDENT WE CAN MAKE IT RIGHT!

If you have any questions or problems with your ELD system, please give us a call before you make a return.

Linxup Customer Support Phone: 1-877-899-3039

Email: support@linxup.com

For more valuable information, please like us on Facebook, and follow us on Twitter and LinkedIn. You can also check out our blog at www.linxup.com/blog



Activate Your Device

- 1 Open a web browser and go to: www.linxup.com/getstarted
- 2 Create an account, or log in to your existing account.

New Customers
Fill out the following to complete your registration:

Activation Code:

E-mail Address:

Create Your Password:

Confirm Password:

I agree to the [Terms & Conditions](#)

Next

Already a Customer?
Simply log in and we'll walk you through the process of adding your new units.

Email Address:


Password:

Sign In

[Forgot Your Password?](#)

If not already on file, you may be prompted for your billing information.

Here's your device activation code:



- 3 Follow the instructions for activating your device(s).

Make sure the activation code in this guide matches the code on screen. Or, if your activation code does not show up re-enter it and press continue.

Set Up eFleetSuite

- 4 Login to the ELD eFleetSuite login page. Sign in using the eFleetSuite credentials emailed to you. Please allow 2-3 business days for delivery.
- 5 Set up your home terminal(s).

A Select 'Home Terminals' in the 'ADMIN' dropdown.

B Click 'New.'

C Fill out the form, then click 'Save.'

- 6 Set up your driver(s). Make sure you have the driver's license number available.

A Select 'Drivers' in the 'SETUP' dropdown.

B Click 'New.'

C Your drivers will use 'Driver ID' to log in to the app.

D Make sure to check the box to give Web Access to drivers.

E Complete the form, then click 'Save.'


The system will create a temporary password for the driver. See the Driver's App Guide for details.

Get to Know the Linxup ELD System


Install Your Device

7 You will need your device, the cord, and the tablet. If you have ordered more than one tablet, you may choose any tablet that you have received, as these have not been paired yet. Begin with the ignition and the tablet powered off.

8 J-BUS Devices: Connect the cord to the device, then plug the device into the J-Bus port.



OBD Devices: Connect the OBD extension cord to the device, then plug the device into the OBDII port.



9 Turn on the ignition, and verify green and orange lights on the device.

10 Power on the tablet. The app will automatically start. The tablet will then recognize all devices within range. The device at the top of the list will be the one closest to you. Double check by matching the serial number, then choose the device.

11 OBD devices only - A pop-up window will prompt you to input the current odometer reading of the vehicle.

Your installation is complete!

Per regulation, for the first 10 days the system may not display available hours on the tablet. The system is still capturing information and generating logs, which are available in the eFleetSuite portal.

Driver Logs

HOME HOS DVIR SETUP ADMIN SETTINGS

Driver: GRAHAM, ROBERT (GRAR87) Date: 5/4/2017 < Previous Day Next Day >

View Logs Print View Edits

Record Date: 5/4/2017 CDT
 24-Hour Starting Time: 12:00 AM
 Time Zone Offset: UTC-05:00

Carrier: Agilis Demo Home Terminal: Main Terminal
 USDOT Number: - 1301 5th St #105
 16305 Swingley Ridge Rd #100 Coralville, IA 52241
 Chesterfield, MO 63017

Driver: GRAHAM, ROBERT
 Driver ID: GRAR87
 Multiday Basis: 8 Days

Print/Display Date: 5/4/2017

MID-NIGHT	1	2	3	4	5	6	7	8	9	10	11	NOON	1	2	3	4	5	6	7	8	9	10	11
OFF	[Bar chart showing OFF status]																						13:56
SB	[Bar chart showing SB status]																						00:00
D	[Bar chart showing D status]																						00:00
ON	[Bar chart showing ON status]																						

Legend: Edited Status (orange square) Gap (pink square)

Total Distance Driven Today: 0 mi (0 km)

Vehicle IDs / VINs: None

Resources: [Edit]

Co-Drivers (IDs)

Click HOS or DVIR for a description of each log, checklist, and report available.

Make your driver and date selections above, then click 'View Logs' to see Driver Logs.

Inspection Checklist

HOME HOS DVIR SETUP

Choose a part, then click here to add a new possible defect which your drivers need to inspect.

Asset Type: Vehicle

View New Part New Defect

Click here to add a new part to your driver's inspection list.

- Defects
 - Brakes (Parking)
 - Other
 - Slow to release
 - Weak or ineffective
 - Will not release
 - Brakes (Service)
 - Air compressor not working
 - Chatters, shudders or vibrates
 - Dragging
 - Leaking air
 - Leaking fluid
 - Other
 - Overheating or running hot
 - Seized
 - Warning light not working
 - Warning light on
 - Weak or ineffective
 - Coupling Devices
 - Fifth wheel cracked or damaged
 - Other
 - Emergency Equipment

Name: Brakes (Parking)

Code: []

Codes will appear in parentheses following the part or defect.

Save Delete

Want to learn more about the Linxup ELD system?

Visit the help pages in your ELD portal to sign up to attend one of our informative webinars!